

Goof Proof® - Application Instructions

For application on cotton, polyester or poly/cotton blends.

1. Set Your Heat Press

If not a Hotronix® heat press, add 10°

Temperature: 360°-370°

Time: 3-5 Seconds

Pressure: Med/Firm 6-8

2. Preheat Your Apparel

- Place apparel on platen
- Press for 3-5 seconds

3. Position Your Transfer & Press

- Place transfer face down on the apparel
- Close machine
- Press for 3-5 seconds

TransferExpress.com/application-tips

4. Peel - Hot

- Open machine
- Peel off the paper in a smooth, even motion and discard.

Tips:

Do not use a pillow.

This product can also be applied at 340° for 10 seconds, peel warm.

Resources:

TransferExpress.com/videos

Helping Your Business Grow

Join us each month for a free online class to grow your knowledge & skills in heat printing, custom transfers & your business. TransferExpress.com/webinars

Join our social community for the latest products, services & tips!

TransferExpress.com/SocialCommunity



Storage and Shelf Life of Your Transfers

Store your transfers in a cool dry place out of extreme hot or cold temperatures or moisture. Keeping them in a sealed bag will prolong the life of the transfers.

First time?

Call us...

We will walk you through!

TransferExpress.com

1-800-622-2280

Monday - Friday
8am - 7pm EST

info@TransferExpress.com



STAHL'S
TRANSFER EXPRESS.